

Cipherlab barcode scanners

Instructions to configure the scanner to read either 10 or 13 digit ISBN barcodes.

13 digit ISBN

1. Scan the *Enter Setup* barcode.
2. Press the trigger and scan the *Enable ISBN 13 Character Conversion* barcode.
3. Press the trigger and scan the *Update* barcode.



Enter Setup



Enable ISBN

13 Character Conversion



Update

10 digit ISBN

1. Scan the *Enter Setup* barcode.
2. Press the trigger and scan the *Enable ISBN 10 Character Conversion* barcode.
3. Press the trigger and scan the *Update* barcode.



Enter Setup



Enable ISBN

10 Character Conversion



Update